

Korenix JetPort Serial Device Server

User's Manual

July 2009 (V1.2)



www.korenix.com

Korenix JetPort Serial Device Server User's Manual

Copyright Notice

Copyright © 2009 Korenix Technology Co., Ltd.

All rights reserved.

Reproduction in any form or by any means without permission is prohibited.

Contents

| | | |
|------------------|--|------------|
| Chapter 1 | Introduction of JetPort | 1-1 |
| | Serial to Ethernet Technology Overview | 1-2 |
| | Product Features | 1-2 |
| | Product Specification | 1-2 |
| | Package Checklist | 1-4 |
| Chapter 2 | Quick Start | 2-1 |
| | Hardware Installation | 2-2 |
| | Panel and Interfaces | 2-2 |
| | Reset Button | 2-2 |
| | LED Indicators | 2-2 |
| | Connecting the Power | 2-3 |
| | Connecting to the Network | 2-3 |
| | Connecting to the Serial Device | 2-3 |
| | Software Setup | 2-3 |
| | Install JetPort Commander | 2-3 |
| Chapter 3 | Windows Management Tool | 3-1 |
| | Server Configuration | 3-2 |
| | Broadcast | 3-2 |
| | Configuration | 3-2 |
| | General | 3-2 |
| | Locate the Device | 3-3 |
| | Security | 3-3 |
| | Networking | 3-4 |
| | Notification | 3-4 |
| | Management | 3-7 |
| | Update Firmware | 3-7 |
| | Save / Reload | 3-7 |
| | Port Configuration | 3-8 |
| | Serial Settings | 3-8 |
| | Advanced Data Packing Options | 3-8 |
| | Service Mode- Virtual COM | 3-9 |
| | Service Mode- TCP Server | 3-11 |
| | Service Mode- TCP Client | 3-13 |
| | Service Mode- UDP | 3-14 |
| | Notification | 3-16 |
| | Setup Wizard | 3-17 |
| | Virtual COM Wizard | 3-18 |
| | Serial Tunnel Wizard | 3-19 |
| | Group IP Wizard | 3-19 |
| | Group Setup Wizard | 3-20 |
| | Group Firmware Wizard | 3-22 |
| | IP Collection | 3-23 |
| | Monitor | 3-24 |
| Chapter 4 | Web and Telnet Console | 4-1 |
| | Web Console | 4-2 |
| | Server Configuration | 4-2 |
| | Port Configuration- Serial Parameter | 4-3 |
| | Service Mode- Virtual COM | 4-4 |
| | Service Mode- TCP Server | 4-5 |
| | Service Mode- TCP Client | 4-5 |

| | |
|--|------------|
| Service Mode- UDP..... | 4-6 |
| Access IP Table..... | 4-6 |
| Event Notification..... | 4-7 |
| Email and SNMP Trap Notification | 4-8 |
| Save / Restart..... | 4-8 |
| Telnet Console | 4-8 |
| Configuration..... | 4-9 |
| Appendix A SNMP MIB II and RS232 Like Support | A-1 |
| Appendix B RS232 Pin Assignment..... | B-1 |

1

Introduction of JetPort

Jetport 5201 is a smart one RS-232 to Ethernet serial device server. It connects the serial port of devices such as card readers, measurement devices, or data acquisition terminals, over Ethernet just like locally attached. JetPort serial device server eliminates the limitation of single host and transmission distance of traditional serial communications by creating access for multiple hosts in Ethernet. The compact size and various mounting options further create installation flexibility.

This chapter describes:

- **Serial to Ethernet Technology Overview**
- **Product features**
- **Product specification**
- **Package checklist**

Serial to Ethernet Technology Overview

Korenix JetPort serial device servers provide perfect solution to manage serial devices via Ethernet in flexible ways, such as TCP server, TCP client, UDP, or Windows virtual COM. JetPort creates a transparent gateway for the serial communication to Ethernet. If the control program uses network standard API, you can choose TCP or UDP as the communication protocol. If the control program uses COM port, you can install the Windows driver to add virtual COM ports.

Product Features

JetPort 5201 has the following features:

- Smart one-port RS232 to Ethernet Solution
- World's highest serial speed: 460.8kbps
- JetPort Commander, Windows utility for auto discovery, multiple device setting and monitoring.
- Versatile serial operation options: Virtual Com, Serial tunnel, TCP server, TCP client, UDP
- Max. 5 Virtual COM, TCP server, TCP client data links
- Configuration by Windows, Web, telnet
- Event warning by Email, SNMP trap
- Virtual COM driver for Windows NT/2000/XP/2003

Product Specification

| Network Interface | |
|--------------------------|---|
| Ethernet | 10/100BaseTX |
| Connector | RJ45 |
| Protection | Built-in 1.5 KV magnetic isolation |
| Protocols | ICMP, IP, TCP, UDP, DHCP, BootP, ARP / RARP, Telnet, DNS, SNMP MIB II, HTTP |
| Serial Interface | |
| Interface | RS-232 |
| Connectors | male DB9 |
| Data Rates | 110 bps to 460.8 Kbps |
| Data Bits | 5, 6, 7, 8 |
| Parity | odd, even, none |
| Stop Bits | 1, 1.5, 2 |
| RS-232 | TxD, RxD, RTS, CTS, DTR, DSR, GND, DCD |
| Flow Control | XON/XOFF, RTS/CTS, DTR/DSR |
| Serial Line | 15KV ESD |

| | |
|------------------------------|--|
| Protection | |
| Software Utility | |
| Utility | <p>JetPort Commander for Windows NT/2000/XP</p> <ul style="list-style-type: none"> ▶ Device discovery ▶ Auto IP report ▶ Device setting (run-time change, no rebooting) ▶ Access control list ▶ Group setting ▶ Device monitoring ▶ Serial port monitoring ▶ Log info ▶ Group Firmware update batch |
| Serial mode | <p>Virtual Com / TCP Server / TCP Client / UDP / Serial Tunnel</p> <ul style="list-style-type: none"> ▶ TCP Alive Check Timeout ▶ Inactivity Timeout ▶ Delimiter for Data Packing ▶ Force TX Timeout for Data Packing |
| Multiple link | 5 Hosts simultaneous connection: Virtual Com / TCP server / TCP Client |
| Virtual Com | Windows NT/2000/XP/2003 |
| Configuration | Web console, Telnet console, JetPort Commander for Windows NT/2000/XP |
| Power Requirements | |
| Power Input | 24VDC (9-30VDC) |
| Power Line protection | <ul style="list-style-type: none"> ▶ 1 KV Burst (EFT), EN61000-4-4 ▶ 0.5 KV Surge, EN61000-4-5 |
| Mechanical | |
| Dimensions | 54.4mmx79.5mmx27mm |
| Regulatory Approvals | FCC Class A, CE Class A RoHS |
| Environmental | |
| Operating Temperature | 0 to 55°C (32 to 131°F) |
| Operating Humidity | 5% to 95% (Non-condensing) |
| Storage Temperature | -20 to 85°C (-4 to 185°F) |

Package Checklist

JetPort is shipped with the following items:

- Korenix JetPort Serial Device Server
- 100-240V Power adapter
- Mounting kit and 4 screws
- 4 Foot pads
- Documentation and Software CD
- Quick Installation Guide



If any of the above items is missing or damaged, please contact your local sales representative.

2

Quick Start


JetPort serial device server can be configured by Windows utility, web browser, or Telnet console. Advanced management features include SNMP support and Email alert. JetPort Commander is a powerful Windows utility that supports device discovery, group setup, group firmware update, and monitoring functions.

This chapter introduces how to quick start JetPort

- **Hardware installation**
- **Software setup**

Hardware Installation

Panel and Interfaces



Reset Button

The Reset button provides users with a quick and easy way to restore the default settings of JetPort. Press reset button for 10 seconds. Release after Power LED blinking orange. JetPort will restore to default value including default IP address (192.168.10.2), and no password. When the Power LED turns green, the device is ready to function.

LED Indicators

There are 3 LEDs, indicating real-time system status.

| LED | Color | Indication |
|------------|--------|--|
| PWR/Ready | Red | On: Power is on and booting up. Blinking: Indicates an IP conflict, or DHCP or BOOTP server did not respond properly. |
| | Green | On: Power is on and functioning normally. Blinking: Located by Administrator's Location function. |
| | Off | Power is off, or power error condition exists. |
| Link / ACT | Green | Blinking: 10 /100Mbps Ethernet connection. |
| | Off | Ethernet cable is disconnected, or has a short. |
| TX / RX | Orange | Serial port is receiving data. |
| | Green | Serial port is transmitting data. |

| | | |
|--|------------|---|
| | Off | No data is being transmitted or received through the serial port. |
|--|------------|---|

Connecting the Power

Connect the power jack input with the enclosed 12VDC power adapter, or 24VDC power input. The power LED will show red color until the system is ready. If the IP setting is running correctly, the power LED will turn green.

Connecting to the Network

Connect the Ethernet cable to the JetPort 10/100M Ethernet port. If the 10M Ethernet is working, the Link/Act LED will blinking orange. If the 100M Ethernet is working, the Link/Act LED will blinking green.


Connecting to the Serial Device

Connect the serial device to JetPort by RS232 interface cable. JetPort serial port is a standard DB9 male port.

Software Setup

Install JetPort Commander


1. Insert the CD and auto-run the program. If the setup does not auto-run, select “JetPort 5201”, and “Operation System”, run JetPort Setup.exe to install Windows utility, JetPort Commander.





2. When the installation is finished, there are three options:
 - ✓ Launch JetPort Commander Now: Start configurations.
 - ✓ Visit Korenix registration page: Register products to Korenix.
 - ✓ Launch JetPort later: Start configurations later.



3. **Broadcast the JetPort unit:** JetPort Commander will broadcast the network and search all available JetPort units in the network. The default IP address of JetPort is "192.168.10.2".

 *Product Tip: If you have multiple Network Adapters (i.e. wireless and wired), please activate ONLY ONE Network Adapter that can locate the JetPort devices, and CLOSE the rest Network Adapters. Otherwise, JetPort Commander may broadcast INCORRECTLY.*




4. **Configuring the JetPort unit:**

4.1 Click on the JetPort unit and select "Add" for further configuring the unit.


4.2 Select "Static IP" if you want to specify the network parameters, or select "DHCP", or "BootP" if you want dynamic configuration for the JetPort unit.

5. Configuring the serial port as COM port:

- 5.1 Go to “Configuration”, and choose the “device” and the “port”. Select “Serial Settings” to configure the serial parameters



- 5.2 Select “Service mode”, “Virtual COM Mode” and press “Map Virtual COM” to map the port to the COM port.



Congratulations! You have finished JetPort configurations with Virtual COM mode. You can also use web or telnet console by the JetPort IP address.

3

Windows Management Tool

JetPort serial device server provides powerful Windows management tool for multiple device management.

This chapter introduces major functions in JetPort Windows Commander

- **Server Configuration**
 - **Broadcast**
 - **Configuration**
 - **General**
 - **Locate**
 - **Security**
 - **Networking**
 - **Notification**
 - **Management**
 - **Firmware Update**
 - **Save / Reload**
- **Port Configuration**
 - **Port Serial Settings**
 - **Port Service Mode**
 - **Port Notification**
- **Setup Wizard**
 - **Virtual COM Wizard**
 - **Serial Tunnel Wizard**
 - **Group IP Wizard**
 - **Group Setup Wizard**
 - **Group Firmware Wizard**
- **IP Collection**
- **Monitor**


Server Configuration

Server configuration covers all settings for the device. Before you start, you need to add the devices first in the configuration list.

Broadcast


After installing JetPort Commander, you can broadcast for all available devices on the network.

Choose “Broadcast” button in the quick bar, and start to search. Select the device you wish to add and click “Add”.



Configuration

In the Configuration menu, you will find the added device in the list. Double click on the device will continue to configure rest of the device settings. The “Refresh” Button will update the latest list of added available devices.



General



The General section lists information of “Model”, “Firmware Version”, “IP Address”, and “MAC Address”.

You can modify Device Name and remark Location information.

Using SNTP Time Server: Enable Time Server by specifying SNTP server IP and Port.



Auto IP Report: If this device uses DHCP or BootP IP, enable Auto IP Report will report its dynamic IP address to the specified host regularly. You can use “Get Current Host” to assign the IP report to be sent to current host. Specify “Report Interval” as to how often the IP address should be sent, zero means no report will be sent.

After modifying configuration, be sure to validate the changes by using “Apply Only” or “Apply and Save”.



*Product Tip: Always save your configurations to validate the changes with 2 options.
Apply Only: Only apply the change one time without saving. When rebooting the device, the changes will not exist.
Apply and Save: The change will be applied and save in Flash. When rebooting the device, the changes are still*

Locate the Device

JetPort Commander can identify one device among the others by the IP address with the “Locate On” function in General Menu. Select the “Locate On”  function and the PWR/Ready LED will blink Green continuously until you select the “Locate Off”  function.

Security

JetPort Security includes access list and administration security.

Access List

The Access IP Table specifies the IP address and subnet that can access to the device. The access is based on IP and netmask combination.

If the access is open to all hosts, do NOT enable this function.

Administration Security

You can assign password to protect others from changing the configurations on the device.

If you assign password, you will need to give password every time when you access Windows, Web, or Telnet consoles. The password will also validate on Setup Wizard configuration.

You can input max. 12 characters as password.

After modifying configuration, be sure to validate the changes by using “Apply Only” or “Apply and Save”.

| Access IP Table | | | |
|-----------------|------|---------|----------------------------------|
| IP1 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |
| IP2 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |
| IP3 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |
| IP4 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |
| IP5 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |
| IP6 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |
| IP7 | Mask | 0.0.0.0 | <input type="checkbox"/> Enabled |

Password

New Password

Confirm New Password

Old Password

Change Password

Networking

JetPort supports both Static IP or DHCP/BootP IP configuration. After modifying configuration, be sure to validate the changes by using “Apply Only” or “Apply and Save”.

General Security **Networking** Notification Management Update Firmware Save/Load

Using Static IP Using DHCP/BOOTP

Static IP Settings

IP Address: 192.168.10.2

Netmask: 255.255.255.0

Gateway: 192.168.10.3

DNS1: 168.95.1.1

DNS2:

Notification

JetPort supports event notification by SNMP trap, email, or system log.

SNMP notification

To activate SNMP notification, check “SNMP management enable” from “Management” menu and assign the “community”, “location”, “contact info”, and Trap Server.

The length of community is from 1 to 31, which cannot be left blank and do NOT include “;” mark.

The length of Location and Contact information is from 0 to 255, which is optional.

The Trap Server supports domain name format, and requires at least one Trap Server information to activate the setting.

Select SNMP Trap in notification menu. Specify the notification event type first and enable SNMP management in Management menu.

- Hardware Reset (Cold Start): Rebooting JetPort from power plug will trigger the event
- Software Reset (Warm Start): Rebooting JetPort from “Reboot Device” function from “Save/Load” menu will trigger the event.

- Login Failed: Using wrong password in console will trigger the event
- IP Changed: Changing network setting will trigger the event
- Password Changed: Changing the password will trigger the event
- Access IP Blocked: Report blocked IP addresses

Email Notification

Enabling Email notification will open a windows for SMTP settings.

Assign SMTP server, and if Authentication is required for the SMTP server, check the authentication box and specify the users name and password.

JetPort supports sending notification to max. 4 email addresses.

General | Security | Networking | Notification | Management | Update Firmware | Save/Load

SNMP Trap Email Notification Syslog Notification

SNMP Settings | Email Settings

Notified Items

Hardware Reset (Cold Start) IP Changed
 Software Reset (Warm Start) Password Changed
 Login Failed Access IP Blocked

SMTP Settings

SMTP Server Port
:: 21

Authentication Required

Email List

Email Address 1
Email Address 2
Email Address 3
Email Address 4

System Log Server Notification

Enabling Syslog Notification will open Syslog Settings window.

Specify Log Server IP, or select “Using Current Host’s Log Server” to specify current host as the log server.

General | Security | Networking | Notification | Management | Update Firmware | Save/Load

SNMP Trap Email Notification Syslog Notification

SNMP Settings | Email Settings | Syslog Settings

Notified Items

Hardware Reset (Cold Start) IP Changed
 Software Reset (Warm Start) Password Changed
 Login Failed Access IP Blocked

System Log Settings

Server IP Port
 0

After modifying configuration, be sure to validate the changes by using “Apply Only” or “Apply and Save”.


Management

In addition to JetPort Windows Commander, JetPort can also be managed by Web and Telnet consoles.

To enable or disable the management consoles, go to “Configuration” and “Management”. JetPort enables Web and Telnet consoles by default. To disable Web or Telnet consoles, uncheck the boxes.

“Go to Web Management” will open web browser and enter web console of JetPort.

“Go to Telnet Management” will open Telnet session and enter telnet console of JetPort.




Choose “Apply Only” or “Apply and Save” to validate the changes.

Update Firmware

You can find up-to-date firmware of JetPort in Korenix website download section.

http://www.korenix.com/support_downloads.htm

To update Firmware of the device, save the firmware file in your host PC. Go to “Configuration”, and “Update Firmware”. Specify the file location by Browsing and continue operation by Update.








The device will reboot after firmware update and be located again in Commander device list.

Note: all configuration will restore to default except for the device IP address after the firmware update.

Save / Reload


After configuration is finished, be sure to Apply and Save the changes.

- | | |
|---|---|
|  | Apply all configurations and Save to Flash. The changes are valid after reboot. |
|  | Load default configuration except Network Settings. |
|  | Reboot the device. |
|  | Retrieve saved configuration file to apply in the device. |
|  | Save the current configuration into a file and save the file in current host. |

Port Configuration

Serial Port Configurations include configuration for the serial parameters, serial communication modes, data packing options, and event notifications.

Go to the port of the device in Configuration tree.



Choose “Apply Only” or “Apply and Save” to validate the changes.

Serial Settings

The available serial settings for JetPort is as follows:

Port Alias: Remark the port to hint the connected device.

Baud rate: from 110bps to 460.8kbps

Parity: No, Even, Odd, Mark, Space

Data Bits: 5, 6, 7, 8

Stop Bits: 1, 2 (1.5)

* 1.5 is only active when data bit is 5.

Flow Control: No, XON/XOFF, RTS/CTS, DTR/DSR

Interface: RS232

Performance: Throughput, Latency


Throughput mode guarantees highest transmission speed

Latency mode guarantees shortest response time

Advanced Data Packing Options

For advanced data packing options, you can specify delimiters for Serial to Ethernet and / or Ethernet to Serial communications.

You can define max. 4 delimiters (00~FF, HEX) for each way. The data will be hold until the delimiters are received or the optional “Flush Ethernet to Serial data buffer” times out. Zero means disable(factory default).



Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. Zero means disable(factory default).


Force TX interval time

0 ms data 1 interval time data 2 interval time data 3


Choose "Apply Only" or "Apply and Save" to validate the changes.

Service Mode- Virtual COM


Virtual COM service mode enables the serial port in JetPort as PC's locally-attached COM port for Windows. One PC can have as many as COM ports on the network without the limitation of PC's physical slots. The Virtual COM ports on the network can also be shared by multiple hosts.




For redundant system considerations, JetPort also supports up to 5 Virtual COM links. Apply same serial setting to the backup host, all the links will transfer data simultaneously.



To start the Virtual COM, select Virtual COM Mode in Service Mode of Port Configuration.




Select "Map Virtual COM" to map the port to PC's COM port.




A Window will appear to confirm to change to Virtual COM mode. Choose Apply Only or Apply and Save.



Select the available port number to map to.




When the configuration is finished and saved, the COM port number will be shown after port, and you can monitor the port in Monitor menu.



Multiple Virtual COM Connections

Max. one connection is default. To create multiple Virtual COM connection, select max. connection number that the JetPort device is allowed. After increasing the max. connection number, other hosts on the same subnet as JetPort can use the port as Virtual COM port at the same time.

Note that all the hosts for the multiple Virtual COM connections must have the same serial parameters, i.e. baud rate, start bit, data bit, etc.



Miscellaneous Settings:

Idle Timeout: When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

Alive Check: The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).




To unmap the COM port, specify the port and select Unmap in the quick bar.

Service Mode- TCP Server

When JetPort is configured as TCP Server, it gives the connected serial device a unique IP:Port address on a TCP/IP network that can be accessed by other network hosts. JetPort as TCP Server waits passively to be contacted by the host computer, allowing the host computer to establish a connection and get data from the serial device.

TCP Server mode supports up to 5 simultaneous connections, so that max. 5 network hosts as TCP Clients can connect to the device at the same time.

Note that all the hosts for the multiple TCP Server connections must have the same serial parameters to communicate with JetPort, i.e. baud rate, start bit, data bit, etc.



TCP Server proceeds as follows:

1. Network host requests a TCP connection with JetPort in TCP Server Mode by IP address and port number.
2. Once the connection is established, data can be transmitted in both directions from the host to the JetPort device, and vice versa.

To configure TCP Server, select TCP Server Mode in Service Mode of Port Configuration.

“Auto Scan” the TCP Data Port number that is available from current host.
The Control Port is Data Port number plus one.

Define the max. connection allowed from 1 to 5.

Apply and Save the changes.  Apply and Save

 Refresh function refreshes the current connections.

The screenshot shows the configuration interface for the JetPort device. The 'Service Mode' is set to 'TCP Server Mode'. The 'TCP Server Settings' section includes 'Data Port' (4000) and 'Control Port' (4001). The 'Misc.' section includes 'Idle Timeout' (0) and 'Alive Check' (0). The 'Multilink' section includes 'Max Connections' (1) and a 'Refresh' button. The 'Destination Host' section includes five rows, each with a 'Disconnect' button.


Miscellaneous Settings:

Idle Timeout: When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

Alive Check: The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).

Service Mode- TCP Client

When JetPort is configured as TCP Client, it will build TCP connection to remote host when data is received. When the connection is built, the data is transmitted bi-directionally. When the data transmission is finished, the TCP connection will be closed by TCP Client. The connect-on-demand TCP Client operation helps the host computer to manage high number of remote devices that exceeds the maximum simultaneous TCP connections allowed. JetPort supports up to 5 simultaneous TCP Client connections for redundant system considerations.



TCP Client proceeds as follows:


1. The JetPort configured as TCP Client Mode requests a connection to the host.
2. Once the connection is established, data can be transmitted in both directions from the host to the JetPort, and vice versa.

To configure TCP Client, select TCP Client Mode in Service Mode of Port Configuration.

Specify the IP and port number of the host. If the TCP Client should connect to the current host, "Auto Scan" will scan current host IP address and available port number. If the TCP Client should connect to other hosts, specify the IP address of the host and "Auto Scan" will scan the available port number of JetPort.

If the TCP Client should connect to more than one host, specify the IP addresses and port number or use "Auto Scan" to scan the port number of JetPort.

Apply and Save the changes. 



Miscellaneous Settings:

Idle Timeout: When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.


Alive Check: device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).

Connect on Startup: The TCP Client will build TCP connection once the connected serial device is startup.

Connect on Any Character: The TCP Client will build TCP connection once the connected serial device starts to send data.

Service Mode- UDP

The UDP Server/Client Mode of operation is designed for applications that require speedy but no-guaranteed data transmission over UDP protocol layer. When JetPort is configured as UDP Server/Client, your serial device can deliver data to multiple destinations at almost the same time since the UDP does not request building connection first before sending data.



To configure UDP, select UDP Mode in Service Mode of Port Configuration.

“Auto Scan” the Listening port number of JetPort.


If there are more than one destination hosts, specify the IP address range by Destination Host IP Begin and End. “Auto Scan” the sending port number of the device.

For example:

Destination Host Begin = 192.168.10.1
 Destination Host End = 192.168.10.100
 Send Port = 4040
 Listening Port = 4032

*JetPort will receive Ethernet data from port 4032 and send to serial port
 *JetPort will receive Serial data to 192.168.10.1 to 192.168.10.100 via port 4040

Apply and Save the changes. 



Notification

Port status can be notified to administrator by means of Email, SNMP trap, or System Log.

The events for notification include:

- DCD changed: When DCD (Data Carrier Detect) signal changes, indicating the modem connection status has changed, the event will be triggered.
- RI changed: When RI (Ring Indicator) signal changes, indicating the incoming of a call, the event will be triggered.
- DSR changed: When DSR (Data Set Ready) signal changes, indicating that the data communication equipment is powered off, the event will be triggered.
- CTS changed: When CTS (Clear To Send) signal changes, indicating that the transmission between computer and DCE can proceed.
- Port connected: In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Virtual COM Mode, when Virtual COM is ready to use, this event will be trigger.
- Port disconnected: In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Virtual COM Mode, When Virtual COM is not available, this event will be trigger.

To enable activate the notification, specify the event type and the notification methods.

The details of SNMP trap Server, Email SMTP server, or Log server IP should be configured first properly in device "Configuration" "Management".

The screenshot shows the 'Management' tab in a configuration interface. The 'Management' tab is highlighted with a blue box. Below the tabs, there are three checked checkboxes: 'Web Management Enable', 'Telnet Management Enable', and 'SNMP Management Enable'. The 'SNMP Management Enable' checkbox is also highlighted with a blue box. Below these checkboxes is a section titled 'SNMP Management Settings' which contains several input fields: 'Community', 'Location', 'Contact', 'Trap Server1', 'Trap Server2', 'Trap Server3', and 'Trap Server4'. The 'SNMP Management Settings' section is enclosed in a blue rounded rectangle.

General | Security | Networking | Notification | Management | Update Firmware | Save/Load

SNMP Trap Email Notification Syslog Notification

SNMP Settings | Email Settings

Notified Items

Hardware Reset (Cold Start) IP Changed
 Software Reset (Warm Start) Password Changed
 Login Failed Access IP Blocked

SMTP Settings

| SMTP Server | Port | User Name | Password |
|----------------------|------|----------------------|----------------------|
| <input type="text"/> | 21 | <input type="text"/> | <input type="text"/> |

Authentication Required

Email List

| | |
|----------------------|----------------------|
| Email Address 1 | Email Address 5 |
| <input type="text"/> | <input type="text"/> |
| Email Address 2 | Email Address 6 |
| <input type="text"/> | <input type="text"/> |
| Email Address 3 | Email Address 7 |
| <input type="text"/> | <input type="text"/> |
| Email Address 4 | Email Address 8 |
| <input type="text"/> | <input type="text"/> |

General | Security | Networking | Notification | Management | Update Firmware | Save/Load

SNMP Trap Email Notification Syslog Notification

SNMP Settings | Email Settings | Syslog Settings


Notified Items

Hardware Reset (Cold Start) IP Changed
 Software Reset (Warm Start) Password Changed
 Login Failed Access IP Blocked

System Log Settings

| Server IP | Port | |
|----------------------|------|--|
| <input type="text"/> | 0 | <input type="button" value="Using Current Host's Log Server"/> |

After modifying configuration, be sure to validate the changes by using “Apply Only” or “Apply and Save”.



Setup Wizard


JetPort Commander offers 5 Setup Wizards to help you manage JetPort devices as a group and streamline the management tasks.




Virtual COM Wizard

JetPort Commander offers one of the easiest way to add serial COM ports over the network by the Virtual COM Wizard. JetPort COM port driver is installed when you install JetPort Commander.


Select the Virtual COM Wizard from Setup Wizard. There are only 3 steps to follow up.




Select the available ports of JetPort devices on the network.



Continue by configuring the serial settings of the serial ports. In Performance mode, there are "Throughput" mode and "Latency" mode. In Throughput mode, the throughput is high. In Latency mode, the response time is fast.



Specify the Virtual COM port range and continue the operation by checking the COM port table.




Serial Tunnel Wizard


The Serial Tunnel Wizard gives you the option to transparently pair two devices over the network.



Select the devices that should be paired and move the devices into IP1 and IP2.




After configuring the serial setting of the ports, the serial tunnel will be built by assigning one port as the TCP Server mode and the other as the TCP Client mode.




Group IP Wizard

When you have more than one device to configure, it is handfull to use Group IP wizard to configure all IP addresses of the devices remotely.


Select Group IP Wizard after opening JetPort Commander, or use Broadcast and find more than one devices on the network and click Group IP Wizard hint at the bottom.



Search the devices in local network (i.e. same subnet), or search by an IP range. Select the devices.




Select the devices for group IP configuration and define the IP addresses range or by DHCP.




Click next to confirm the setup and the IP configuration is finished, you will see the IP addresses for the devices.

Group Setup Wizard


Group Setup Wizard helps you to copy the configuration of one device to other devices. You can select the items to be copied or not. Go to "Setup Wizard", "Group Setup Wizard", and choose "Next" to continue.




Select device model as “JetPort 5201”.




Select the source device for the configuration and destination devices.



Specify the configuration items from the source device to the destination devices.



Click next to confirm and finish the wizard.




Group Firmware Wizard

To update firmware for a group of devices can be as easy as 4 steps of Group Firmware Wizard.




Select the device model as JetPort 5201, and select available devices on the network for the upgrade.



Specify the firmware image and select next. Confirm the firmware upgrade and continue operation. JetPort Commander will upgrade firmware of the devices and reboot again to finish.






IP Collection


For the dynamic DHCP IP settings, it is often a task to find the changing IP addresses.

JetPort Commander supports auto IP report function to report the current IP address of the JetPort units to administrator. To enable the function, check “Auto IP Report” in “Configuration”, “General”. Specify the host that the device should report IP to, or define current host as the report host.

Be sure to define the Report Interval time. Zero is disable.




Go to the IP Collection function of the main menu and find the devices auto IP report list.



Monitor

You can monitor the COM port status from the Monitor function. The monitored items can also be defined by the “Select Monitor Items”. You must configure the COM ports first before monitoring the status.



4

Web and Telnet Console

In addition to Windows utility, JetPort can also be managed by Web and Telnet Console.

This chapter describes:

■ **Web Console**

- Server Configuration
- Port Configuration
- Management
- Save / Restart

■ **Telnet Console**

- Overview
- Configuration

Web Console

When the JetPort has been configured with proper IP address and the web management is enabled, you can use web browser to make further configurations.

Type JetPort's IP address in the Address input box, for example 192.168.10.5.

If the JetPort is password protected, use the pre-assigned password to login first.



Password Protected

Password:

The overview page lists the basic information of this JetPort device.



Go to Korenix · Help

korenix JETPORT

Welcome to JetPort Web Commander

Overview

| | |
|------------------|-------------------|
| Model Name | JetPort5201 |
| IP address | 192.168.10.5 |
| MAC Address | 00:12:77:12:23:45 |
| Firmware Version | 0.97b |

Server Configuration

- Overview
- Basic Setting
- Network Setting
- Change Password

Port Configuration

- Serial Parameters
- Service Mode

Management

- Access IP Setting
- E-mail and SNMP Trap
- Event Notification

Save / Restart

Server Configuration

Basic Setting configures Server name, Time Server, and Telnet console enable/disable.

Basic Setting

Device name/Location

Time

Time zone

Local time Thu Jan 1 00:28:59 1970

Time server

Console

Telnet console Enable Disable

Network Setting configures the IP address, netmask, gateway, and DNS server for the JetPort. Auto IP report is for dynamic IP address reporting in defined intervals.

Network Setting

IP configuration

IP address

Netmask

Gateway

DNS server 1

DNS server 2

IP Address report

Auto report to IP

Auto report to TCP port

Auto report period seconds

You can also define Administration password to protect the JetPort from unauthorized modification. Avoid using space in password.

Change Password

Old Password:

New Password:

Confirm New Password:

Port Configuration- Serial Parameter

Port Configuration covers Serial Parameter settings, such as baud rate, data bits, stop bits, parity, and flow control.

Port Alias: Remark the port to hint the connected device.

Baud rate: from 110bps to 460.8kbps

Parity: No, Even, Odd, Mark, Space

Data Bits: 5, 6, 7, 8

Stop Bits: 1, 2 (1.5)

Flow Control: No, XON/XOFF, RTS/CTS, DTR/DSR

Interface: RS232

Performance: Throughput, Latency

Throughput mode guarantees highest transmission speed
Latency mode guarantees shortest response time

For advanced data packing options, you can specify delimiters for Serial to Ethernet and / or Ethernet to Serial communications.

You can define max. 4 delimiters (00~FF, HEX) for each way. The data will be hold until the delimiters are received or the optional "Flush Ethernet to Serial data buffer" times out. Zero means disable(factory default).

Serial Setting

Port alias
Interface RS232

Serial Parameters

Baud rate
Data bits
Stop bits
Parity
Flow control
Force TX Timeout seconds
Performance throughput latency

Delimiter Setting

Mode Serial to Ethernet
Delimiter Timeout ms
Delimiter(Hex 0~ff) 1: 2: 3: 4:
Mode Ethernet to Serial
Delimiter Timeout ms
Delimiter(Hex 0~ff) 1: 2: 3: 4:

Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. Zero means disable(factory default).

Service Mode- Virtual COM

In Virtual COM mode, you need to define the available port number, Idle timeout, Alive check, and Max. connections allowed from 1 to 5.

Service Mode

Operating Mode:

Virtual COM Port

Idle Timeout seconds

Alive Check seconds

Multilink Count

Idle Timeout: When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

Alive Check: The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).

Service Mode- TCP Server

In TCP Server mode, you need to define the available port number, Idle timeout, Alive check, and Max. connections allowed from 1 to 5.

Service Mode

Operating Mode:

TCP Server Port

Idle Timeout seconds

Alive Check seconds

Multilink Count

Idle Timeout: When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

Alive Check: The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).

Service Mode- TCP Client

In TCP Client mode, you need to define the destination host IP and port number, Idle timeout, Alive check. To deploy multilink, specify up to 4 more hosts IP and Port number.

Service Mode

Operating Mode:

Destination Host :

Idle Timeout seconds

Alive Check seconds

Connect on Startup Any Character

max. connection (1~5)

| Destination Host | Port |
|-------------------------|----------------------|
| 1. <input type="text"/> | <input type="text"/> |
| 2. <input type="text"/> | <input type="text"/> |
| 3. <input type="text"/> | <input type="text"/> |
| 4. <input type="text"/> | <input type="text"/> |

Idle Timeout: When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

Alive Check: The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).

Connect on Startup: The TCP Client will build TCP connection once the connected serial device is startup.

Connect on Any Character: The TCP Client will build TCP connection once the connected serial device starts to send data.

Service Mode- UDP

In UDP mode, you need to define the destination host IP and Local listen port number.

To create more destination hosts, specify the IP range of destination IP and send port number.

Service Mode

Operating Mode:

Destination Host

Listen Port

Multilink

| Host start IP | Host end IP | Send Port |
|-------------------------|----------------------|----------------------|
| 1. <input type="text"/> | <input type="text"/> | <input type="text"/> |
| 2. <input type="text"/> | <input type="text"/> | <input type="text"/> |
| 3. <input type="text"/> | <input type="text"/> | <input type="text"/> |
| 4. <input type="text"/> | <input type="text"/> | <input type="text"/> |

Access IP Table

The Access IP Table specifies the IP address and subnet that can access to the device. The access is based on IP and netmask combination.

If the access is open to all hosts, do NOT enable this function.

Access IP Setting

| No. | IP Address | Netmask |
|-----|----------------------|----------------------|
| 1 | <input type="text"/> | <input type="text"/> |
| 2 | <input type="text"/> | <input type="text"/> |
| 3 | <input type="text"/> | <input type="text"/> |
| 4 | <input type="text"/> | <input type="text"/> |
| 5 | <input type="text"/> | <input type="text"/> |
| 6 | <input type="text"/> | <input type="text"/> |
| 7 | <input type="text"/> | <input type="text"/> |
| 8 | <input type="text"/> | <input type="text"/> |
| 9 | <input type="text"/> | <input type="text"/> |
| 10 | <input type="text"/> | <input type="text"/> |
| 11 | <input type="text"/> | <input type="text"/> |
| 12 | <input type="text"/> | <input type="text"/> |

Event Notification

Specify the events that should be notified to the administrator. The events can be alarmed by means of email, SNMP trap, or system log.

Device Notification:

- Hardware Reset (Cold Start): Rebooting the JetPort will trigger the event
- Software Reset (Warm Start): Restarting the computer will trigger the event
- Login Failed: Using wrong password in console will trigger the event
- IP Changed: Changing network setting will trigger the event
- Password Changed: Changing the password will trigger the event
- Access IP Blocked: Report blocked IP addresses

Port Notification:

- DCD changed: When DCD (Data Carrier Detect) signal changes, indicating the modem connection status has changed, the event will be triggered.
- RI changed: When RI (Ring Indicator) signal changes, indicating the incoming of a call, the event will be triggered.
- DSR changed: When DSR (Data Set Ready) signal changes, indicating that the data communication equipment is powered off, the event will be triggered.
- CTS changed: When CTS (Clear To Send) signal changes, indicating that the transmission between computer and DCE can proceed.
- Port connected: In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Virtual COM Mode, when Virtual COM is ready to use, this event will be trigger.
- Port disconnected: In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Virtual COM Mode, When Virtual COM is not available, this event will be trigger.

Email and SNMP Trap Notification

Email Server configuration includes the mail server's IP address or domain. If the authentication is required, specify the username and password. There are 4 email addresses you can specify to receive the notification.

Mail server
Mail server

My server requires authentication

Username

Password

E-mail address 1

E-mail address 2

E-mail address 3

E-mail address 4

SNMP Trap configuration includes up to 4 Trap Servers. You need to at least fill in one Trap Server's IP or domain. The Community is also required information. Do not use the “;” in this column. Location and Contact is optional information.

SNMP trap server

SNMP Server 1

SNMP Server 2

SNMP Server 3

SNMP Server 4

Community

Location


Contact

Save / Restart

Load Factory Default: Load default configuration except Network Settings.
Import Configuration: Retrieve saved configuration file to apply in the device.
Export Configuration: Save the current configuration into a file and save the file in current host.
Upgrade Firmware: Upgrade to new firmware

Telnet Console

Telnet the IP of JetPort, you will enter the Telnet console menu.



```
Telnet 192.168.10.2
*****
*      Korenix Jetport Commander      *
*****
-----
[Korenix Jetport Commander]
1. Overview
2. General Settings
3. Network Settings
4. Ports settings
5. Security(Accessible IP) Settings
6. Notification(Auto Warning) Settings
C. Change Password
L. Load Factory Default
S. Save configuration
R. Reboot
Q. Exit & Logout

Select one function <1-6,C,L,S,R,Q>:
```

Configuration

Configure the device and port by pressing function number or the hinted initial.

Press “q” to exit the function.

Always press “a” to apply and save change after making a configuration.

A

SNMP MIB II and RS232 Like Support

Jetport 5201 has build-in SNMP agent that supports SNMP trap, RFC 1317 RS232 MIB and RFC1213 MIB-II. The following tables list SNMP variables implemented in Jetport 5201.

RFC1213 MIB-II supported SNMP variables

| System MIB | | | | |
|-------------|-----------------|-----------|------------|-------------|
| sysDescr | sysObjectID | sysUpTime | sysContact | sysName |
| sysLocation | sysORLastChange | sysORID | sysORDescr | sysORUpTime |
| | | | | |

| Interface MIB | | | | |
|---------------|---------------|---------------|--------------|----------------|
| ifNumber | ifIndex | ifDescr | ifType | ifMtu |
| ifSpeed | ifPhysAddress | ifAdminStatus | ifOperStatus | ifInOctets |
| ifInUcastPkts | ifInDiscards | ifInErrors | ifOutOctets | ifOutUcastPkts |
| ifOutDiscards | ifOutErrors | ifOutQLen | ifSpecific | |

| Address MIB | | | | |
|-------------|---------------|--------------|--|--|
| atIfIndex | atPhysAddress | atNetAddress | | |

| IP MIB | | | | |
|-----------------|-------------------|------------------|---------------|----------------|
| ipForwarding | ipDefaultTTL | ipInReceives | ipInHdrErrors | ipInAddrErrors |
| ipForwDatagrams | ipInUnknownProtos | ipInDiscards | ipInDelivers | ipOutRequests |
| ipOutDiscards | ipOutNoRoutes | ipReasmTimeout. | ipReasmReqds | ipReasmOKs |
| ipReasmFails | ipFragOKs | ipFragFails | ipFragCreates | ipAdEntAddr |
| ipAdEntIfIndex | ipAdEntNetMask | ipAdEntBcastAddr | ipRouteDest | ipRouteIfIndex |

| | | | | |
|-------------------|---------------------|-------------------------|------------------------|------------------|
| ipRouteMetric1 | ipRouteNextHop | ipRouteType | ipRouteProto | ipRouteMask |
| ipRouteInfo | ipNetToMediaIfIndex | ipNetToMediaPhysAddress | ipNetToMediaNetAddress | ipNetToMediaType |
| ipRoutingDiscards | | | | |

ICMP MIB

| | | | | |
|----------------------|------------------|---------------------|----------------------|------------------|
| icmpInMsgs | icmpInErrors | icmpInDestUnreaches | icmpInTimeExcds | icmpInParmProbs |
| icmpInSrcQuenchs | icmpInRedirects | icmpInEchos | icmpInEchoReps | icmpInTimestamps |
| icmpInTimestampReps | icmpInAddrMasks | icmpInAddrMaskReps | icmpOutMsgs | icmpOutErrors |
| icmpOutDestUnreaches | icmpOutTimeExcds | icmpOutParmProbs | icmpOutSrcQuenchs | icmpOutRedirects |
| icmpOutEchos | icmpOutEchoReps | icmpOutTimestamps | icmpOutTimestampReps | icmpOutAddrMasks |
| icmpOutAddrMaskReps | | | | |

TCP MIB

| | | | | |
|-------------------|-----------------|----------------|---------------------|------------------|
| tcpRtoAlgorithm | tcpRtoMin | tcpRtoMax | tcpMaxConn | tcpActiveOpens |
| tcpPassiveOpens | tcpAttemptFails | tcpEstabResets | tcpCurrEstab | tcpInSegs |
| tcpOutSegs | tcpRetransSegs | tcpConnState | tcpConnLocalAddress | tcpConnLocalPort |
| tcpConnRemAddress | tcpConnRemPort | tcpInErrs | tcpOutRsts | |
| | | | | |

UDP MIB

| | | | | |
|----------------|------------|-------------|-----------------|-----------------|
| udpInDatagrams | udpNoPorts | udpInErrors | udpOutDatagrams | udpLocalAddress |
| udpLocalPort | | | | |
| | | | | |

SNMP MIB

| | | | | |
|---------------------|--------------------|-----------------------|-------------------------|------------------------|
| snmpInPkts | snmpOutPkts | snmpInBadVersions | snmpInBadCommunityNames | snmpInBadCommunityUses |
| snmpInASNParseErrs | snmpInTooBig | snmpInNoSuchNames | snmpInBadValues | snmpInReadOnly |
| snmpInGenErrs | snmpInTotalReqVars | snmpInTotalSetVars | snmpInGetRequests | snmpInGetNexts |
| snmpInSetRequests | snmpInGetResponses | snmpInTraps | snmpOutTooBig | snmpOutNoSuchNames |
| snmpOutBadValues | snmpOutGenErrs | snmpOutGetRequests | snmpOutGetNexts | snmpOutSetRequests |
| snmpOutGetResponses | snmpOutTraps | snmpEnableAuthenTraps | snmpSilentDrops | snmpProxyDrops |

RFC1317 RS232 supported SNMP variables

RS232 MIB

| | | | | |
|-------------|----------------|---------------|----------------------|-----------------------|
| rs232Number | rs232PortIndex | rs232PortType | rs232PortInSigNumber | rs232PortOutSigNumber |
|-------------|----------------|---------------|----------------------|-----------------------|


| | | | | |
|--------------------------|---------------------------|---------------------------|----------------------|------------------------|
| rs232PortInSpeed | rs232PortOutSpeed | rs232PortInFlowType | rs232PortOutFlowType | |
| rs232AsyncPortIndex | rs232AsyncPortBits | rs232AsyncPortStopBits | rs232AsyncPortParity | rs232AsyncPortAutobaud |
| rs232AsyncPortParityErrs | rs232AsyncPortFramingErrs | rs232AsyncPortOverrunErrs | | |
| rs232InSigPortIndex | rs232InSigName | rs232InSigState | rs232InSigChanges | |
| rs232OutSigPortIndex | rs232OutSigName | rs232OutSigState | rs232OutSigChanges | |

B

RS232 Pin Assignment

| Pin No. | Name | Notes/Description |
|---------|------|-------------------------|
| 1 | DCD | Data Carrier Detect |
| 2 | RD | Receive Data (RxD, Rx) |
| 3 | TD | Transmit Data (TxD, Tx) |
| 4 | DTR | Data Terminal Ready |
| 5 | SGND | Ground |
| 6 | DSR | Data Set Ready |
| 7 | RTS | Request To Send |
| 8 | CTS | Clear To Send |
| 9 | RI | Ring Indicator |

RS232 DB9 Male



C

Revision History

| Version | Description | Date |
|---------|-------------------------------|-----------|
| V1.0 | The first version. | Mar. 2006 |
| V1.1 | Correct Serial Port LED color | Oct. 2008 |
| V1.2 | Remove Linux TTY driver | July 2009 |